

6380329

Recliner

SALE



**\$100
OFF**

Was:
\$395

\$295

RELAXATION

Relax in a recliner chair while relieving fatigue and feeling comfortable and supported. You will have a blissful moment, free from your busy daily life.

リラクゼーション

リクライニングチェアで疲れを癒し、心地よいサポート感を感じながらリラックス。忙しい日常から解き放たれた至福のひとときをお過ごしください。



MOVIE VIEWING

Recliners are ideal for watching movies. Enjoying a movie in a recliner chair allows you to immerse yourself in the world of the movie even more. The comfortable seating and relaxing effect will allow you to enjoy the movie without stress.

映画鑑賞

リクライニングチェアは映画鑑賞に最適です。リクライニングチェアで映画を楽しめば、より一層映画の世界に浸ることができる。快適な座り心地とリラックス効果で、ストレスなく映画を楽しむことができる。



Dimensions

サイズ



•Width: 45.00"
•幅 : 114.3cm



•Height: 47.00"
•高さ : 119.4cm






•Depth: 43.00"
•奥 : 109.2cm

Size Carton

Inches

Carton Size

	Width	41 inches
	Depth	34 inches
	Height	35 inches

Centimeter

箱のサイズ

	幅	104.1cm
	奥	86.4cm
	高	88.9cm




ASSEMBLY INSTRUCTIONS

WARNING! This unit must be assembled in the order shown. Failure to do so may result in damage to the parts or impede function of the unit.

STEP1: To install "easy-off chair back", slide inside back receivers(1) onto the steel mechanism posts(2) in the base of the furniture (Figure A).

STEP2: Press both sides seat back from the top downward firmly into place. The inside back automatically locks into place.

STEP3: To remove the backs, use a screwdriver pulling outward on the block tab in the metal sleeve (Figure B) on both sides of the inside back receivers (1) and lift the back off the base of the furniture



組立説明書

警告 本機は、必ず表示された順序で組み立ててください。この順番を守らないと、部品が破損したり、本機の機能に支障をきたすことがあります。

ステップ 1: イージー・オフ・チェアの背もたれ」を取り付けるには、背もたれ受け(1)を家具の土台にあるスチール支柱(2)にスライドさせます(図 A)。

ステップ 2: 両側のシートバックを上から下へしっかりと押し込んでください。背もたれの内側が自動的にロックされます。

ステップ 3: 背もたれを取り外すには、ドライバーを使い、背もたれ(1)の内側にある両側の金属スリーブ(図 B)にあるネジ山を外側に引っ張り、背もたれを持ち上げて家具のベースから外します。

